

Lecture#5:


Thin Films



Oxidation

Thin films

If some film has below 1um (~10um) thickness, we call it thin film
 ex) Metal, semiconductor, insulator thin film



Silicon Oxidation



Oxidation

Principal uses

- Insulating layer in device and between metal lines (t_{ox} = 50~200Å)
- **Passivation layer** to seal silicon surface (i.e. diffusion barrier) $(t_{ox} = 0.5^{2} \text{ m})$
- **Blocking layer** to stop or mask impurity atoms $(t_{ox} = ~1 \text{ um})$

Silicon Oxide (SiO₂)

- i) Easy and simple fabrication process; upon exposure to oxygen, the surface of a silicon wafer oxidizes to form silicon dioxide.
- ii) Good insulating property: >10⁷V/cm (Thermal oxide), 10⁶V/cm (CVD oxide)
- iii) Etching selectivity with Si material ex) ZnO


Thermal Oxidation



Oxidation

Thermal oxidation process

- Thermal oxidation of silicon is easily achieved by heating the wafer to a high temperature, typically 900 to 1200 C, in an atmosphere containing either pure oxygen or water vapor.



Kinetics of Oxidation




Oxidation

- Ory oxidation (O_2 gas) Si (solid/wafer) + $O_2 \rightarrow SiO_2$ (Solid)
- Wet oxidation (water vapor)
 Si (solid/wafer) + 2H₂O → SiO₂ (Solid) + 2H₂




Question) To growth 1um SiO₂, what is the thickness of Si being consumed?



- In order for oxidation to occur, oxygen must reach the silicon surface. As the oxide grows, oxygen must pass through more and more oxide, and the growth rate decrease as time goes on.

[Note] 0.46 t_{ox} is important





Comparison (Dry & Wet)



	Dry oxidation	Wet oxidation
process	$Si + O_2 \rightarrow SiO_2$	$Si + 2H_2O \rightarrow SiO_2 + 2H_2$
grow rate	low	high
quality	high (dense)	low
application	MOS gate oxide	Etch mask



Modeling (1)



Oxidation

Fick's first law of diffusion

- the particle flow per unit area, J (particle flux), is directly proportional to the concentration gradient of the particle:


$$J = -D \frac{\partial N(x,t)}{\partial x}$$

where D is the diffusion coefficient and N is the particle concentration.

For the case of silicon oxidation

- it is assumed that the oxygen flux (F) through the oxide is constant; oxygen does not accumulate in the oxide. $D(C_1 - C_2)$

 $F_1 = \frac{D(C_0 - C_s)}{x}$



where X is the thickness of the oxide, and C_o and C_s are the concentrations of the oxidizing species in the oxide at the oxide surface and silicon dioxide-silicon interface, respectively.

- (at the SiO₂ and Si interface) the oxidation rate is proportional to the concentration of the oxidizing species:

$$F_2 = kC_s$$

where k is called the rate constant for the reaction at the Si-SiO₂ interface

Modeling (2)



Oxidation

- In steady state

$$F = \frac{D(C_0 - C_s)}{x} = kC_s$$
$$F = \frac{DC_0}{x + (\frac{D}{k})}$$

- The rate of change of thickness of the oxide layer

$$\frac{dx}{dt} = \frac{Flux}{C_1} = \frac{F}{C_1} = \frac{DC_0/C_1}{x + (\frac{D}{k})}$$
of the oxidizing species

Let solve differential equation (1st order),

$$t = \frac{x^2}{B} + x/(\frac{B}{A}) - \tau$$

$$A = 2D/k$$

$$B = 2DC_0/C_1$$

$$x = 0.5A \left[\sqrt{1 + \frac{4B}{A^2}(\tau + t)} - 1 \right]$$

* τ represents the time which would have been required to grow the initial oxide.

Modeling (3)



Oxidation

$$x = 0.5A \left[\sqrt{1 + \frac{4B}{A^2}(\tau + t)} - 1 \right]$$

$$A = 2D/k$$

$$B = 2DC_0/C_1$$

$$x = \frac{D}{\kappa} \left[\sqrt{1 + \frac{2C_0 \kappa^2 (t + \tau)}{DC_1}} - 1 \right]$$

For small values of t,

$$x \cong \frac{C_0 \kappa}{C_t} (t + \tau)$$

For large values of t,

$$x \equiv \sqrt{\frac{2DC_0}{C_1}(t+\tau)}$$

i) Short time
$$(t+\tau) \ll A^2/4B$$

$$x = \frac{B}{A}(t + \tau)$$
 Key) 1.B/A is **linear rate constant**
2.Growth rate just depends on time
; Linear dependence
3. Limit is the reaction of Si surface


ii) Long time
$$(t + \tau) \gg A^2/4B$$
 $t \gg \tau$

Rate Constant



Oxidation


Linear rate constant



Why (111) substrate has higher growth rate?

Available bonding density is higher than that of (100)

Parabolic rate constant




Wet oxidation (H_2O) rate is faster than dry oxidation (O_2) Generally, 5~10 times faster

Growth Rate




Oxidation

Oxide thickness



Dry oxidation: Low growth rate
Film quality is good
showing best electrical properties
<20nm, gate oxide



Wet oxidation: High growth rate

Film quality is not good

Electrically not bad


>20nm, Mask or passivation

Various Pressure



Oxidation

Oxide thickness with various partial pressure



Thin Oxide Growth

- -Slow growth : Good quality and reproducibility
 - 1. Dry oxidation
 - 2. Low temperature (**800C** ~**900C**)
 - 3. Low partial pressure of oxygen

Process Parameters (1)



Oxidation

1) Temperature, Time, Initial oxide thickness (major parameter)

Conditions	Oxidation rate	Oxidation thickness
Lower Temp. Thin oxide	Reaction-limited (linear rate)	t _{ox} ∞ Time
Higher Temp. Thick oxide	Diffusion-limited (parabolic rate)	t _{ov} ∝ ime"-

- 2) Pressure
 - at low temperature (reaction limited)
 - pressure ↑, grow rate ↑

Process Parameters (2)




- 3) Crystal orientation
 - R(111) > R(100) # of silicon bonds to be broken at surface
- 4) Impurity / Dopant type
 - n type (linear rate)
 - p type (parabolic rate)
 - → dopant redistribution during oxidation process (segregation coefficient & diffusion coefficient)
- 5) Impurity / Dopant / Defect Concentration
 - High dopant concentration
 - → point defects exist (voids, interstitial atoms)
 - → increase surface reaction rate


Characterization for Oxide Thickness



Oxidation



Ellipsometry: detect the polarization change



Profilometry (α -step) : mechanical movement

